

OKI

MULTIFUNCTIONAL DIGITAL COLOR SYSTEMS

Hardware Troubleshooting Guide

ES9466 MFP/ES9476 MFP

Preface

Thank you for purchasing OKI Multifunctional Digital Systems. This manual describes how to troubleshoot the problems that could occur while you are using the equipment. Keep this manual within easy reach, and use it to configure an environment that makes the best use of the OKI MFP's functions.

This equipment provides the scanning/printing function as an option. However, this optional scanning/printing function is already installed in some models.

■ How to read this manual

□ Symbols in this manual

In this manual, some important items are described with the symbols shown below. Be sure to read these items before using this equipment.

 **WARNING** Indicates a potentially hazardous situation which, if not avoided, could result in death, serious injury, or serious damage, or fire in the equipment or surrounding objects.

 **CAUTION** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, partial damage to the equipment or surrounding objects, or loss of data.

 **Note**

Indicates information to which you should pay attention when operating the equipment.

 **Tip**

Describes handy information that is useful to know when operating the equipment.



Pages describing items related to what you are currently doing. See these pages as required.

□ Target audience for this manual

This is a manual that is aimed at general users and administrators.

□ Options

For the available options, refer to the **Quick Start Guide** for this equipment.

□ Screens in this manual

- The details on the screens may differ depending on your model and how the equipment is used, such as the status of the installed options, the OS version and the applications.
- The illustration screens used in this manual are for paper in the A/B format. If you use paper in the LT format, the display or the order of buttons in the illustrations may differ from that of your equipment.

□ Abbreviations in this manual

In this manual, “Dual Scan Document Feeder” is referred to as “DSDF” and “Reversing Automatic Document Feeder” as “RADF”, and they are collectively referred to as “Automatic Document Feeder” (ADF).

□ Trademarks

For trademarks, refer to the **Safety Information**.

CONTENTS

Preface	3
How to read this manual	3

Chapter 1 TROUBLESHOOTING FOR THE HARDWARE

When This Screen Is Displayed	9
Messages Displayed on the Touch Panel	13
Clearing a Paper Jam	18
Locating a paper jam	18
Clearing a paper jam.....	19
ADF.....	21
Tray feeding portion	27
Large Capacity Feeder	28
Paper Feed Pedestal	28
Trays	29
Envelope Tray	30
Large Capacity Feeder	30
MPT	31
Automatic duplexing unit.....	32
Paper transport path	33
Fuser unit.....	34
Bridge Kit.....	36
Finisher and Hole Punch Unit.....	36
Saddle Stitch Finisher and Hole Punch Unit.....	42
Saddle Stitch unit of the Saddle Stitch Finisher.....	46
Inner Finisher and Hole Punch Unit	52
Clearing paper jams caused by a wrong paper size setting.....	55
Clearing a Staple Jam	60
Finisher.....	60
Saddle Stitch unit	65
Replacing a Toner Cartridge	67
Replacing a “Near Empty” toner cartridge	69
Replacing the Waste Toner Box	72
Refilling With Staples	74
Finisher.....	74
Saddle Stitch unit	77
Cleaning the Inside of the Equipment	80
The Main Chargers and Slit Glass	80
Cleaning the Hole Punch Dust Bin	84
Finisher / Saddle Stitch Finisher Hole Punch Unit	84
Inner Finisher Hole Punch Unit	84
When Printed Sheets Overflow from the Stacker	87

Chapter 2 WHEN SOMETHING IS WRONG WITH THE EQUIPMENT

When You Think Something Is Wrong With the Equipment	90
General operations	90
Originals and paper	91
Regular Maintenance	93

INDEX	95
--------------------	-----------

1

TROUBLESHOOTING FOR THE HARDWARE

This chapter describes how to troubleshoot problems with paper, toner and other finishing processes.
This chapter also describes how to supply the paper, toner and staples.


When This Screen Is Displayed	9
Messages Displayed on the Touch Panel	13
Clearing a Paper Jam	18
Locating a paper jam	18
Clearing a paper jam.....	19
ADF.....	21
Tray feeding portion	27
Large Capacity Feeder	28
Paper Feed Pedestal	28
Trays	29
Envelope Tray	30
Large Capacity Feeder	30
MPT	31
Automatic duplexing unit.....	32
Paper transport path	33
Fuser unit.....	34
Bridge Kit.....	36
Finisher and Hole Punch Unit.....	36
Saddle Stitch Finisher and Hole Punch Unit.....	42
Saddle Stitch unit of the Saddle Stitch Finisher.....	46
Inner Finisher and Hole Punch Unit	52
Clearing paper jams caused by a wrong paper size setting.....	55
Clearing a Staple Jam	60
Finisher.....	60
Saddle Stitch unit	65
Replacing a Toner Cartridge	67
Replacing a “Near Empty” toner cartridge	69
Replacing the Waste Toner Box.....	72
Refilling With Staples.....	74
Finisher.....	74
Saddle Stitch unit	77
Cleaning the Inside of the Equipment.....	80
The Main Chargers and Slit Glass	80
Cleaning the Hole Punch Dust Bin	84
Finisher / Saddle Stitch Finisher Hole Punch Unit	84


Inner Finisher Hole Punch Unit84




When Printed Sheets Overflow from the Stacker87



When This Screen Is Displayed

Various screens are displayed on the touch panel depending on the state of the equipment. This section describes how to solve problems with some of the screen examples.

Screen	Description / Remedy
	<p>A message appears on the upper part of the screen to notify users of a problem, etc. For the major examples, see the following pages. P.13 “Messages Displayed on the Touch Panel”</p>

Screen	Description / Remedy
	<p>An incorrect paper size or “⚠---” indicates an unsuccessful paper size detection. In this case, check the following items.</p> <ul style="list-style-type: none"> • Check if the paper with an unacceptable size is placed in the tray. For details about the acceptable paper size, refer to the Specifications Guide. • Check if the paper with a non-standard size is placed in the tray. Press [Custom] to set the paper size manually. • Check if there is too much space between the paper and the side and end guides of the tray. Set the paper, the side guide and the end guide to the appropriate position again. • Check if [Auto (inch)] is selected even though A/B format paper has been placed. Check if [Auto (mm)] is selected even though LT format paper has been placed. Press the button which corresponds to the format of the paper set in the tray and then set the paper again. If a different paper size is displayed even though a standard size paper has been placed, set the paper size manually. To do so, the change of the setting by the administrator is required. For details, refer to the MFP Management Guide.

Screen	Description / Remedy
	<p>The original or copy paper is jammed. Remove it following the guidance on the touch panel. P.18 “Clearing a Paper Jam”</p>
	<p>A cover is open. Check which cover on the touch panel and then close it securely.</p>
	<p>Toner has run out. Replace the new toner cartridge. P.67 “Replacing a Toner Cartridge”</p>

Screen	Description / Remedy
	<p>The waste toner box is full. Replace it following the guidance on the touch panel.</p> <p>📖 P.72 “Replacing the Waste Toner Box”</p>
	<p>The equipment requires adjusting by a service technician. Contact your service representative with the error code displayed on the right side of the touch panel.</p> <p>⚠️ WARNING _____</p> <p>Never attempt to repair, disassemble or modify the equipment by yourself. You could cause a fire or get an electric shock. Always contact your service representative for maintenance or repair of the internal parts of the equipment.</p>

Messages Displayed on the Touch Panel

A message appears on the upper part of the screen to notify users of a problem, etc. The major examples of problems and how to solve them are described in the table below.

Message	Problem Description	Corrective Action
Close *** cover.	The cover indicated by *** is open.	Check the cover on the touch panel and close it.
Jam in ***	Paper jam has occurred inside the equipment.	Remove the jammed paper following the guidance displayed on the touch panel. 📖 P.18 “Clearing a Paper Jam”
Install new *** toner cartridge	No toner is left. (“***” indicates the applicable color.) (The colors are shown abbreviated when two or more toners are running out: Y: yellow, M: magenta, C: cyan, and K: black)	See the color indication on the touch panel and replace the toner cartridge. (About another 50 copies can be made after this message appears. The number varies depending on the conditions of copying.) 📖 P.67 “Replacing a Toner Cartridge”
*** Toner Not Recognized Check the toner cartridge	The toner cartridge indicated by *** is not installed at all or improperly so.	Install the toner cartridge correctly. 📖 P.67 “Replacing a Toner Cartridge”
	The terminal of the toner cartridge is stained.	Wipe the terminal with a soft cloth.
	The recommended toner cartridge is not being used.	Use the recommended toner cartridge. 📖 P.67 “Replacing a Toner Cartridge”
Check paper size setting on control panel for tray N. Check the direction or size of the paper.	Paper jam has occurred because of the mismatch between the paper size placed in tray N and the size registered for the tray N in the equipment.	Just removing the jammed paper does not prevent another paper from being jammed. Be sure to correctly register the paper size in the equipment. 📖 P.55 “Clearing paper jams caused by a wrong paper size setting”
Wait (Performing Self-check)	The equipment is undergoing maintenance to keep its imaging quality.	Wait until the adjustment is completed and the message disappears.
Adjusting. Wait until printing resumed.	The equipment is performing the adjustment of its inside temperature.	Wait until the adjustment is completed and the message disappears.
Time for cleaning. Open the front cover and follow the guidance.	The main charger, LED print head or slit glass needs cleaning.	Clean the main charger, LED print head and slit glass. 📖 P.80 “Cleaning the Inside of the Equipment”
Check the original and set it again	The original is jammed inside of the ADF.	Remove the jammed original following the guidance on the touch panel. 📖 P.21 “ADF”
	The direction or the size of the original placed on the ADF is incorrect.	Check the direction and the size of the original and then replace it on the ADF. Then reattempt the operation.
Change direction of original	The orientation of the original placed on the original glass is incorrect.	Change the orientation of the original by 90 degrees and place it on the original glass.

Message	Problem Description	Corrective Action
Cannot print this paper size Select the other tray.	Printing was attempted but failed. The paper could not be output on the stacker selected for the paper output because of a mismatch between the paper size and the stacker.	Delete the failed print job, select the appropriate stacker for the paper, and perform printing again. For the restrictions of the paper type and the receiving stackers, refer to the Quick Start Guide .
Cannot print this paper type Set the other paper type	Printing was attempted but failed. The paper could not be output in the stacker selected because of a mismatch between the paper type and the stacker. (Special paper, thick 4 paper or thin paper tried to be output on the lower receiving stacker of MJ-1109/MJ-1110.)	Delete the failed print job, select the appropriate stacker for the paper, and perform printing again.
Change from this mode Count over, cannot store anymore	The number of originals to be scanned has exceeded the limit specified with the department or user code during scanning.	Ask your administrator for details of setting the limit for the number of copies.
Ready(***) Toner Not Recognized) Check the toner cartridge	The toner cartridge indicated by *** is not installed at all or improperly so.	Install the toner cartridge correctly.  P.67 "Replacing a Toner Cartridge"
	The terminal of the toner cartridge is stained.	Wipe the terminal with a soft cloth.
	The recommended toner cartridge is not being used.	Use the recommended toner cartridge.  P.67 "Replacing a Toner Cartridge"
Ready (Saddle Stitch Stacker Full)	The saddle stitch stacker of the finisher is full of paper.	Remove the paper from the saddle stitch stacker of the finisher.
Ready (Check Saddle Stitch Stapler)	A staple jam has occurred in the stapler of the saddle stitch unit or the staple sheet has not been fed sufficiently.	Remove the top staple sheet.  P.65 "Saddle Stitch unit"
Ready (Check Saddle Stitch Stapler)	Staples in the stapler of the saddle stitch unit have almost run out or have actually done so.	Replace the staple case of the saddle stitch unit if stapling is not performed for an output document even though the stapling function has been selected.  P.77 "Saddle Stitch unit"
Ready (Check Stapler)	Staple jam has occurred in the stapler of the finisher.	Remove the jammed staples.  P.60 "Clearing a Staple Jam"
Ready (Check Stapler)	Staples in the stapler of the finisher have almost run out or have actually done so.	Replace the staple case of the finisher if stapling is not performed for an output document even though the stapling function has been selected.  P.74 "Refilling With Staples"
Ready (Hole Punch Dust Bin is Full)	Hole punch dust bin is full of paper punchings.	Remove the paper punchings.  P.84 "Cleaning the Hole Punch Dust Bin"
Ready (Finisher Full)	The receiving stacker of the finisher is full of paper.	Remove the paper from the receiving stacker of the finisher.
Ready (Face Down Stacker Full)	The stacker of the equipment is full of paper.	Remove the paper from the stacker of the equipment.

Message	Problem Description	Corrective Action
Cannot copy Check Department Counter	The number of originals to be scanned has exceeded the limit specified with the department code during scanning.	Ask your administrator for details of setting the limit for the number of copies.
Add paper	No paper is left in a tray or on the MPT.	Set paper in the tray or on the MPT. The touch panel indicates which tray (or the MPT) has no paper. To set paper, refer to the Copying Guide .
Call for Service	The equipment requires adjusting by a service technician.	Contact your service representative with the error code displayed on the right side of the touch panel. ⚠ WARNING _____ Never attempt to repair, disassemble or modify the equipment by yourself. You could cause a fire or get an electric shock. Always contact your service representative for maintenance or repair of the internal parts of the equipment.
Examine stapler in the saddle Stitch unit	Staple jam has occurred in the stapler of the saddle stitch unit.	Remove the jammed staples. 📖 P.65 "Saddle Stitch unit"
Check staple cartridge in the saddle stitch unit	Staples in the stapler of the saddle stitch unit have almost run out or have actually done so.	Replace the staple case of the saddle stitch unit if stapling is not performed for an output document even though the stapling function has been selected. 📖 P.77 "Saddle Stitch unit"
Check staple cartridge	Staples in the stapler of the finisher have almost run out or have actually done so.	Replace the staple case of the finisher if stapling is not performed for an output document even though the stapling function has been selected. 📖 P.74 "Refilling With Staples"
Examine Stapler	Staple jam has occurred in the stapler of the finisher.	Remove the jammed staples. 📖 P.60 "Clearing a Staple Jam"
Saving power - press Power Save button.	The equipment has entered into the energy saving mode since it has not been used for a certain time.	Press [POWER SAVE] button to clear the power saving mode.
Change tray to Correct Paper Size	No paper suitable for the original is set.	Place the suitable size paper for the original in the tray.
	The size of the original is not detected correctly because the original is sent from the ADF at a skew.	Replace the original while aligning the side guides of the ADF to its width so that it will be placed straight.
Time for periodic maintenance	The equipment requires inspection and maintenance by a service technician.	Contact your service representative for maintenance.
Power Failure	A job was interrupted by a power failure or some other reason.	The print or fax job may be incomplete. Press [Job Status] to check whether any jobs are unfinished. To clear the messages, press the [RESET] button twice.

Message	Problem Description	Corrective Action
Erasing Data	The Data Overwrite Enabler is clearing the data.	This message is displayed if the Data Overwrite Enabler is installed. You can operate the equipment while the message is displayed.
Check paper size setting on control panel for MPT. Check the direction or size of the paper.	Paper jam has occurred because of a mismatch between the paper size placed in the MPT and the size registered for the MPT in the equipment.	Register the paper size correctly. Just removing the jammed paper does not prevent another paper from being jammed.  P.55 “Clearing paper jams caused by a wrong paper size setting”
Set the paper on the MPT again.	The paper placed on the MPT jammed.	Remove the jammed paper and set the paper again.
Check the direction or size of the paper on the MPT and press START	The direction or the size of the paper placed on the MPT is incorrect.	Check the direction and the size of the paper and then replace it on the MPT.
	The side guides of the MPT do not fit the paper length.	Align the side guides of the MPT to the paper length.
Reboot the machine	A system-related trouble has occurred.	Press the [POWER] button, and then [Shutdown] or [Restart] on the touch panel.
Toner near Empty (***)	Toner is running out. “****” indicates the color. (The colors are shown in abbreviations when two or more toners are running out: Y: yellow, M: magenta, C: cyan, and K: black)	Some toner is still left in the toner cartridge while this message is displayed. You do not have to replace the toner cartridge yet. Check the color of the toner on the touch panel and prepare the toner cartridge. (About another 1000 copies can be made after this message appears. Depending on the conditions of copying, this message may not appear even when the toner cartridge is near empty.) Notes <ul style="list-style-type: none"> • Replace the toner cartridge after the toner has completely run out. [Install new *** toner cartridge] is displayed at that time. • If you want to replace the toner cartridge though some toner is still left, follow the procedure below:  P.69 “Replacing a “Near Empty” toner cartridge” • Black and white print is available while the other colors has run out. Neither color nor black and white print can be done when the black toner has run out.
Dispose of used toner	The waste toner box is full.	Replace the waste toner box following the guidance displayed on the touch panel.  P.72 “Replacing the Waste Toner Box”
Please empty hole punch waste	The Hole Punch Unit dust bin is full.	Remove the paper punchings.  P.84 “Cleaning the Hole Punch Dust Bin”
Fax line1 (or line2) is out of order.	The 1st (or 2nd) line for the fax unit is not working.	Contact your service representative.
Fax line1 (or line2) is not installed.	The 1st (or 2nd) line for the fax unit is not installed.	Contact your service representative.

Message	Problem Description	Corrective Action
This original is copy protected	An attempt is made to copy a prohibited original.	This original cannot be copied.
DEPARTMENT Quota exceeded. Contact the Administrator.	The copying, printing or scanning quota to the department has reached "0".	For details of setting the quota, ask your administrator.
Not enough Work Space to store originals Will you print out stored originals?	Internal memory available ran out while scanning.	To print out the data for the originals stored (scanned) until the message appeared, press [Yes] on the touch panel. To delete the stored data, press [No].
USER Quota exceeded. Contact the Administrator.	The copying, printing or scanning quota to the user has reached "0".	For details of setting the quota, ask your administrator.
USER and DEPARTMENT Quota exceeded. Contact the Administrator.	The copying, printing or scanning quota to the user and department has reached "0".	For details of setting the quota, ask your administrator.
Check under the Finisher stacker and reboot the machine.	An obstruction is placed under the Finisher stacker.	Remove the obstruction under the Finisher stacker and reboot the equipment.
The number of originals exceeds the limits. The scanned data will be deleted.	The number of originals to be scanned has exceeded the limit of 1000 sheets during scanning. (The magazine sort or page number function is used.)	Reduce the number of originals to be scanned, and try again.
The number of originals exceeds the limits. Will you copy stored originals?	The number of originals to be scanned has exceeded the limit of 1000 sheets during scanning.	To print out the data for the originals stored (scanned) until the message appeared, press [Yes] on the touch panel. To delete the stored data, press [No].
LAN cable is not detected	The LAN cable connection is not detected.	<p>Check the following items.</p> <ul style="list-style-type: none"> • Check that the LAN cable is connected to the equipment. • Check that there is no damage on the connector of the LAN cable. • Check that the LAN cable is open circuited. • Check that the LAN cable is connected to the HUB. Check that there is no damage to the connector. • Check that the power is ON for the HUB to which the LAN cable is connected. • Check that the settings of the communication speed and the Ethernet method for the equipment and the HUB are aligned.


Error Codes

The error codes indicating the status of the equipment may appear on the touch panel. For details, please refer to the **Software Troubleshooting Guide**.


Clearing a Paper Jam

■ Locating a paper jam

The equipment stops copying when the original or copy paper is jammed. Paper jams are notified on the touch panel as follows:



The paper jam symbol helps you locate the paper jam.




1. RADF or DSDF (lower) (📖 P.21)
2. RADF or DSDF (upper) (📖 P.21)
3. Bridge Kit (📖 P.36)
4. Fuser unit (📖 P.34)
5. Automatic duplexing unit (📖 P.32)
6. MPT (📖 P.31)
7. Tray feeding portion (📖 P.27)
8. Large Capacity Feeder (📖 P.28) or Paper Feed Pedestal (📖 P.28)
9. Paper transport path (📖 P.33)
10. Trays (📖 P.29), Envelope Tray (📖 P.30) or tray of the Large Capacity Feeder (📖 P.30)
11. Saddle stitch unit (📖 P.46)
12. Finisher (📖 P.36, 📖 P.42, 📖 P.52)
13. Hole Punch Unit (📖 P.36, 📖 P.42, 📖 P.52)

The picture of the hardware device shown on the touch panel differs depending on the options installed.

■ Clearing a paper jam

1 Clear the paper jam.

Clear the paper jam following the guidance shown on the touch panel. Press  or  to scroll the pages.



2 After clearing the jam, close all the opened covers.

The equipment starts the warm-up. Follow the guidance on the touch panel.

□ Tips on removing the jammed paper

Note the following points in removing the jammed paper.

Remove the jammed paper carefully so as not to tear it.

To avoid tearing the jammed paper, remove the paper slowly with both hands. Using force may tear the paper, making it more difficult to remove. See also that no pieces of torn paper are left inside the equipment.

When the paper jam sign remains after removing the jammed paper:

Depending on the timing of the occurrence, no jammed paper may be found where the paper jam sign indicates. If the sign does not disappear after you have removed the jammed paper, follow the steps as instructed on the touch panel.


Do not touch the connectors inside the equipment.

This could cause a malfunction.

Do not touch the fuser unit or the metal portion around it.


⚠ CAUTION

Do not touch the fuser unit or the metal portion around it when you remove the paper jammed in the right side of the equipment. This could burn you or the shock could cause you to get your hand injured in the machine.



Do not touch the transfer belt.

When you remove the paper jammed in the right side of the equipment, be sure not to touch the transfer belt. This could stain copy images.



❑ If paper jams occur frequently


The following are the common causes of paper jams. If the problem persists, check for the following situations.

- An unsuitable original is placed on the ADF.
- Unavailable paper with the equipment is used.
- Paper sizes are not consistent between the size in a tray or the MPT and the size registered in the equipment.
- All the jammed paper has not been removed.
- There is too much of a gap between the paper and the side or end guide in the tray.
- The amount of paper placed in a tray exceeds the limit indicated on the side guide of the tray.


■ ADF

□ RADF (Lower)


1 Open the RADF.



2 Lower the green lever, open the reverse cover and remove the original.




3 Close the RADF.




□ RADF (Upper)


1 Raise the lever and open the upper cover.




2 Remove the original.




3 Turn the inner green dial and remove the jammed original.



4 Raise the green lever and open the transport guide.




5 Raise the green lever under the transport guide, and remove the original under the guide plate.




6 Close the transport guide.

7 Raise the original feeder tray, and remove the original under the tray.




8 Lower the original feeder tray.

9 Close the upper cover.




DSDF (Lower)


1 Remove the originals on the DSDF and open it.




2 Push the green button to open the lower cover.




3 Turn the inner green dial and remove the jammed original.




4 Remove the jammed originals.



5 Push the green part to close the lower cover.




6 Close the DSDF.




□ DSDF (Upper)


1 Raise the lever and open the upper cover.




2 Remove the jammed originals.




3 If it is not easy to remove the jammed originals under the feed roller unit, take it off.




4 Remove the jammed originals under the feed roller unit.




5 Attach the feed roller unit.



6 Remove the originals under the original feeder tray.



7 Close the upper cover.




Note


Confirm that the lever of the upper cover is closed firmly.

■ Tray feeding portion


- 1 Open the feeder cover on the right side.



- 2 Remove the jammed paper from the tray and close the feeder cover.




If the paper is jammed on the cover side, remove it as shown in the figure below.




■ Large Capacity Feeder

- 1 Open the feeder cover of the Large Capacity Feeder on the right.




- 2 Remove the jammed paper and close the feeder cover.




■ Paper Feed Pedestal

- 1 Open the feeder cover of the Paper Feed Pedestal on the right.




- 2 Remove the jammed paper and close the feeder cover.




■ Trays

- 1 Open the paper source tray, and remove the jammed paper.



- 2 Check that the guide width is correct, there is no folded/curled paper or overloading, and then close the tray.




Note


Be sure that the height of the stacked paper does not exceed the line indicated inside of the side guides.

■ Envelope Tray

- 1 Open the paper source tray, and remove the jammed paper.



- 2 Check that the guide width is correct, there is no folded/curled paper or overloading, and then close the tray.




Note


Be sure that the height of the stacked paper does not exceed the line indicated inside of the side guides. In particular, be sure that the upper limit for envelope is not exceeded when placing envelope in the Envelope Tray. The amount of envelope you can load in the tray is lower than that for plain paper.

■ Large Capacity Feeder


- 1 Open the tray of the Large Capacity Feeder.



- 2 Pull out the right-hand tray and remove the jammed paper.



- 3 Check that there is no folded/curled paper or overloading, and then close the tray of the Large Capacity Feeder.




Note


Be sure that the height of the stacked paper does not exceed the line indicated inside of the side guides.

■ **MPT**

- 1 Move the green paper holding lever toward the outside. The paper can now be removed.



- 2 Pull out the jammed paper in the MPT.



- 3 Place paper in the MPT again and then move the green paper holding lever toward the inside. If a sheet of paper is stained, folded or torn, replace it with a new one.




■ Automatic duplexing unit

⚠ CAUTION


Be careful not to let your fingers be caught between the equipment and the duplexing unit cover or automatic duplexing unit cover.

This could injure you.


- 1 Open the automatic duplexing unit cover on the right.



- 2 Remove the jammed paper.



- 3 While holding the green lever, remove the jammed paper.




- 4 Lower the green lever carefully and then close the automatic duplexing unit cover.

■ Paper transport path


⚠ CAUTION

Be careful not to let your fingers be caught between the equipment and the duplexing unit cover or automatic duplexing unit cover.
This could injure you.

1 Open the automatic duplexing unit cover on the right.




2 Remove the jammed paper.



Notes

- Be sure not to touch the transfer belt when removing the jammed paper. This could stain copy images.
- Do not clean roller [A] though it may be stained. It will be automatically cleaned at the next printing.

3 Open the transport guide toward you and remove the jammed paper.



Note

Be sure not to touch the photoconductive drum when removing the jammed paper. This could stain copy images.


4 Close the automatic duplexing unit cover.

■ Fuser unit

⚠ CAUTION


- **Be careful not to let your fingers be caught between the equipment and the duplexing unit cover or automatic duplexing unit cover.**
This could injure you.
- **Do not touch the fuser unit or the metal portion around it.**
Since they are very hot, you could be burned or the shock could cause you to get your hand injured in the machine.

1 Open the automatic duplexing unit cover on the right.




2 Open the transport guide holding the green knob and then release the jammed paper. Pull the jammed paper up or down as shown in the illustrations depending on the position of the paper.


Pulling it up




Pulling it down




3 Remove the paper from the exit section.




4 When the finisher is installed, open the Bridge Kit cover while holding the handle.



5 Remove the jammed paper.




6 When the finisher is installed, close the Bridge Kit cover.




7 Close the automatic duplexing unit cover.

■ Bridge Kit

- 1 Open the cover holding the handle of the Bridge Kit.



- 2 Remove the jammed paper inside the Bridge Unit.



Tip


If the jammed paper cannot be removed because the right side is caught by the fuser unit, follow the steps on  P.34 "Fuser unit".

- 3 Close the Bridge Kit cover.


■ Finisher and Hole Punch Unit

Paper jam in the upper receiving stacker

- 1 Raise the lever and open the upper receiving stacker of the finisher.




- 2 Remove the jammed paper.



3 Open the cover holding the handle of the Bridge Unit.



When the Hole Punch Unit is installed, proceed to step 5.

**4 Remove the jammed paper.**

Proceed to step 8.




When the Hole Punch Unit is installed

5 Open the Hole Punch Unit cover.**6 Turn the green knob to get the jammed paper out.****Note**

Be sure to turn the knob to the direction indicated by the arrow to remove the jammed paper. If you pull out the paper forcibly without turning the knob, this may tear the paper.

7 Close the Hole Punch Unit cover.



8 Close the Bridge Kit cover.

9 Close the upper receiving stacker of the finisher.

Place your hands on the near and far side of the lever and push to close the stacker until it clicks.



⚠ CAUTION

Be careful not to let your fingers be caught between the finisher body and the Stacker (Upper) of the finisher.

This could injure you.


Tip

The upper receiving stacker can also be closed by pressing the right side of the lever.




Paper jam in the lower receiving stacker


1 Raise the lever and open the upper receiving stacker of the finisher.



2 Remove the jammed paper.




3 Remove the jammed paper.




Tip

If the paper is caught by the roller in the exit section, remove it by lifting the roller up with your fingers.



4 Open the cover holding the handle of the Bridge Unit.

When the Hole Punch Unit is installed, proceed to step 6.




5 Remove the jammed paper.

Proceed to step 9.




When the Hole Punch Unit is installed

6 Open the Hole Punch Unit cover.




7 Turn the green knob to get the jammed paper out.



Note

Be sure to turn the knob to the direction indicated by the arrow to remove the jammed paper. If you pull out the paper forcibly without turning the knob, this may tear the paper.

8 Close the Hole Punch Unit cover.



9 Close the Bridge Kit cover.

10 Close the upper receiving stacker of the finisher.
Place your hands on the near and far side of the lever and push to close the stacker until it clicks.



⚠ CAUTION

Be careful not to let your fingers be caught between the finisher body and the stacker (Upper) of the finisher.
This could injure you.


Tip

The upper receiving stacker of the finisher can also be closed by pressing the right side of the lever.




■ Saddle Stitch Finisher and Hole Punch Unit


- 1 Raise the lever and open the upper receiving stacker of the finisher.




- 2 Open the cover of the Hole Punch Unit when it is installed.




- 3 Open the front cover of the finisher.




- 4 Remove the jammed paper from the right or left.



5 Open the cover holding the handle of the Bridge Unit.



6 Remove the jammed paper inside the Bridge Unit.





7 If the paper size is small, turn the knob shown in the following figures to send the paper, and then remove the jammed paper.

Note

When the Hole Punch Unit is installed, open the front cover of the finisher and turn the 2 knobs at the same time.


When the Hole Punch Unit is not installed

When the Hole Punch Unit is installed




Be sure to turn the knob to the direction indicated by the arrow to remove the jammed paper. If you pull out the paper forcibly without turning the knob, this may tear the paper.

8 Remove the jammed paper.



Tip


If the paper is caught by the roller in the exit section, remove it by lifting the roller up with your fingers.



9 Close the cover of the Bridge Unit.

10 Close the upper receiving stacker of the finisher.

Place your hands on the near and far side of the lever and push to close the stacker until it clicks.




⚠ CAUTION

Be careful not to let your fingers be caught between the finisher body and the stacker (Upper) of the finisher.


This could injure you.

Tip


The upper receiving stacker of the finisher can also be closed by pressing the right side of the lever.



11 Close the cover of the Hole Punch Unit when it is installed.




12 Close the front cover of the finisher.




■ Saddle Stitch unit of the Saddle Stitch Finisher


- 1 Remove the jammed paper from the exit side of the Saddle Stitch unit.




- 2 Open the front cover of the finisher.




- 3 Holding the green knob, move the guide to the right.



- 4 Raise the lever and open the upper receiving stacker of the finisher.



5 Open the cover of the Hole Punch Unit when it is installed.




6 Turn the knob shown in the following figures to send the paper, and then remove the jammed paper.


Note

When the Hole Punch Unit is installed, open the front cover of the finisher and turn the 2 knobs at the same time.

When the Hole Punch Unit is not installed



When the Hole Punch Unit is installed




Be sure to turn the knob to the direction indicated by the arrow to remove the jammed paper. If you pull out the paper forcibly without turning the knob, this may tear the paper.

Some jammed paper may get inside of the Saddle Stitch unit depending on the location where the jamming occurs. In this case, follow step 7.

7 Close the upper receiving stacker of the finisher.

Place your hands on the near and far side of the lever and push to close the stacker until it clicks.




⚠ CAUTION

Be careful not to let your fingers be caught between the finisher body and the stacker (Upper) of the finisher.


This could injure you.

Tip


The upper receiving stacker of the finisher can also be closed by pressing the right side of the lever.




8 Turn the green knob to lower the paper until it is hidden.



9 Holding the green knob, return the guide to the left.




10 Pull out the Saddle Stitch unit until it stops.




⚠ CAUTION

Do not put your hands in the opening section (A) which is located behind the Saddle Stitch unit.
Your hands may be caught, resulting in injury.


11 Open the transport guide on the right side.




12 Remove the jammed paper.




13 Remove the paper from the inside of the Saddle Stitch unit.




14 Close the transport guide.




15 Holding both green knobs with your fingers, open the transport guide on the left.




16 Lower the two green levers.




17 Remove the paper.




18 Raise the two green levers.




19 Holding both green knobs with your fingers, close the transport guide on the left.




20 Return the Saddle Stitch unit to its original position.



21 Close the cover of the Hole Punch Unit when it is installed.




22 Close the front cover of the finisher.




■ Inner Finisher and Hole Punch Unit


- 1** Lift up the control panel and then open the front cover of the finisher.




- 2** While holding the green lever, move the finisher to the left until it stops.




- 3** Pull down the green lever on the right-hand unit of the finisher.
The paper exit of the equipment opens.




- 4** Turn the green dial clockwise to send the paper and remove it.




5 Return the green lever to its original position.




6 When the Hole Punch Unit is installed and used for punching holes, while pulling the green dial toward you, turn it to align the yellow marks on the parts.




7 Turn the upper green dial counterclockwise to remove the jammed paper.




8 Turn the upper green dial clockwise to remove the jammed paper.




9 Holding the green knob, open the upper cover.




10 Remove the jammed paper and then close the upper cover.




11 While holding the green lever, open the Hole Punch Unit to remove the jammed paper.



12 Return the Hole Punch Unit to its original position.




13 Carefully return the finisher to its original position.



⚠ CAUTION


Do not put your hand or fingers on the top of the finisher when closing it.
They could be caught and this could injure you.

14 Close the front cover of the finisher.



■ Clearing paper jams caused by a wrong paper size setting

Paper jams occur when there is a mismatch between the size of the paper in a tray or the MPT and the size registered for the corresponding tray or the MPT in the equipment. The message “Check paper size setting on control panel for tray N. Check the direction or size of the paper.” or “Check paper size setting on control panel for MPT. Check the direction or size of the paper.” appears on the touch panel.



In this case, just clearing the jammed paper does not prevent another paper from being jammed. Be sure to follow the procedure below.

Troubleshooting differs depending on how the paper jam has occurred:


- 📖 P.56 “Jam when making copies or prints (using a tray)”
- 📖 P.58 “Jam when making copies or prints (using the MPT)”
- 📖 P.59 “Jam when printing from the Fax”

❑ Jam when making copies or prints (using a tray)


- 1 Clear the paper jam following the guidance shown on the touch panel.**
- 2 Open the paper source tray, check that the guide width is correct and there is no folded/curled paper or overloading, and then close the tray.**

Note

Be sure that the height of the stacked paper does not exceed the line indicated inside of the side guides.



- 3 Close all the trays or covers.**
- 4 Press [Yes] when “Cancel print job?” appears.**
The print job is canceled.




If you do not want to cancel the print job


To restart the job without canceling it, replace the paper in the tray with that corresponding to the size set in the equipment after the paper jam is cleared. Then if you press [No] in step 4, the job can be restarted. In this case, it is not necessary to follow step 5 and later.

- 5 Press [Setting - User-] on the touch panel to access the Setting menu.**


6 Press the [User] tab to enter the User menu and press [Tray].



7 Press the tray button indicated in the message.



8 Set the paper size again and press [OK].




Tip

For details about how to set the paper size, refer to “Doing Paper Settings” in Chapter 1 of the *Paper Preparation Guide*.

9 Press the [HOME] button to return to the basic menu. Then press [Copy] to enter the copy menu.

10 Confirm that the paper size is correctly detected if you selected [Auto (mm)] or [Auto (inch)] in step 8.

The detected paper size is indicated on the tray button in the equipment status indication area on the left.




An incorrect paper size or “⚠️ ---” indicates an unsuccessful detection. In this case, see the following page.
📖 P.9 “When This Screen Is Displayed”

11 Try copying or printing again.

❑ Jam when making copies or prints (using the MPT)

1 Clear the paper jam following the guidance shown on the touch panel. Then close all the covers.

2 Press [Yes] when “Cancel print job?” appears.
The print job is canceled.



If you do not want to cancel the print job

To restart the job without canceling it, replace the paper on the MPT with that corresponding to the size set in the equipment after the paper jam is cleared. Then if you press [No] in step 2, the job can be restarted. In this case, it is not necessary to follow step 3 and later.


3 Place the paper on the MPT and set the paper size.

4 Try copying or printing again.


❑ Jam when printing from the Fax

1 Pull out the tray in which paper jams occurred and remove all the paper from it.

If such paper jams occur although [Auto (mm)] or [Auto (inch)] has been selected as the paper size, this is caused by the incorrect size detection of the paper placed in the tray. In this case, do not remove the paper and proceed to step 3.




2 Place the paper corresponding to the set size in the tray.



3 Check that the guide width is correct and there is no folded/curled paper or overloading, and then close the tray.

Note

Be sure that the height of the stacked paper does not exceed the line indicated inside of the side guides.



4 Clear the paper jam following the guidance shown on the touch panel. Then close all the trays and covers.

Printing resumes.

Clearing a Staple Jam

When a staple jam has occurred in the stapler of the finisher or saddle stitch unit, clear the jam following the procedure below.


📖 P.60 “Finisher”

📖 P.65 “Saddle Stitch unit”


■ Finisher

□ Finisher / Saddle Stitch Finisher


1 Open the front cover of the finisher.



2 Remove the staple cartridge.



3 Lower the guide while holding the knob.




⚠ CAUTION


Do not touch the stapling area.

The actual needle point could cause you personal injury.


4 Remove the top staple sheet.



5 Holding the knob, raise the guide, and return it to its original position.




6 Remove the staples if they have fallen between the staple cartridge and the staple case or in the staple receiver.



7 Fit the staple cartridge into the stapler.

When fitting the staple cartridge, hold the green-labeled portion of the bracket securely so that the bracket will not move.


Insert the cartridge until it is caught by the latch and fixed with a click.




8 Close the front cover of the finisher.

□ Inner Finisher


- 1 Lift up the control panel and then open the front cover of the finisher.




- 2 While holding the green lever, move the finisher to the left until it stops.




- 3 Open the Hole Punch Unit while pushing the green lever.



- 4 Remove the staple cartridge.




5 Lower the guide while holding the knob.




⚠ CAUTION

Do not touch the stapling area.
The actual needle point could cause you personal injury.


6 Remove the top staple sheet.



7 Holding the knob, raise the guide, and return it to its original position.




8 Remove the staples if they have fallen between the staple cartridge and the staple case or in the staple receiver.




9 Fit the staple cartridge into the stapler.


Insert the cartridge until it is caught by the latch and fixed with a click.



10 Return the Hole Punch Unit to its original position.




11 Carefully return the finisher to its original position.



⚠ CAUTION


Do not put your hand or fingers on the top of the finisher when closing it.
They could be caught and this could injure you.

12 Close the front cover of the finisher.




■ Saddle Stitch unit


- 1 Open the front cover of the finisher, and pull out the Saddle Stitch unit until it stops.



- 2 Remove the staple cartridge.



- 3 Raise the guide while holding the knob.




⚠ CAUTION


Do not touch the stapling area.

The actual needle point could cause you personal injury.


- 4 Remove the top staple sheet.




5 Holding the knob, lower the guide, and return it to its original position.



6 Fit the staple cartridge.
Insert the cartridge until it is caught by the latch and secured with a click.



7 Return the Saddle Stitch unit to its original position. Close the front cover of the finisher.



Replacing a Toner Cartridge

When the toner cartridge runs out, the message “Install New *** (color name) toner cartridge” appears. Replace the toner cartridge following the procedure below when you see this message.


⚠ WARNING

Never attempt to incinerate toner cartridges.

Dispose of used toner cartridges and waste toner boxes in accordance with local regulations.

Do not touch the terminal of the toner cartridge.


This may cause the equipment not to recognize the toner cartridge or may damage the terminal.




Tip

Some toner is still left in the toner cartridge while the message “Toner near Empty” is displayed. You do not have to replace the toner cartridge yet, but if you choose to do so, follow the procedure [P.69](#) “Replacing a “Near Empty” toner cartridge”.

1 Open the front cover of the equipment.



2 Put your fingers on the right side of the toner cartridge and pull it out supported with your left hand.




⚠ WARNING


Never attempt to incinerate toner cartridges.

Dispose of used toner cartridges and waste toner boxes in accordance with local regulations.


- 3** Shake the new toner cartridge strongly with its label side down to loosen the toner inside.




- 4** Pull the seal straight out in the direction of the arrow.



- 5** Align the new toner cartridge to the guide. Insert it up to the black line.




- 6** Pull out the cleaner until the mark appears and return it. Repeat this 3 times for each of the 4 colors.



Note


The cleaner cannot be removed by design. Pulling it out forcibly may cause malfunction.

7 Close the front cover pressing both edges.




■ Replacing a “Near Empty” toner cartridge

The message “Toner near Empty” appears on the touch panel when there is not much toner left in a toner cartridge.




Some toner is still left in the toner cartridge while the message “Toner near Empty” is displayed. You do not have to replace the toner cartridge yet, but if you choose to do so, follow the procedure below.


1 Press [Job Status].




2 Press the [Toner] tab.



3 Press [Replace Toner Cartridge].




4 To replace a toner cartridge, press [Yes]. To cancel, press [No].



If you press [Yes], go to the next step. If you press [No], the previous screen appears.

5 Press the button for the color you intend to replace.



6 To replace the toner cartridge, press [Yes]. To cancel, press [No].




If you press [Yes], go to the next step. If you press [No], the previous screen appears.

7 Replace the toner cartridge.

See P.67 “Replacing a Toner Cartridge” for the correct procedure.

8 Press [Finish].



Replacing the Waste Toner Box


When the waste toner box becomes full, the symbol for replacement of the waste toner box blinks and the message “Dispose of used toner” appears. Replace the waste toner box following the procedure below.

⚠ WARNING


Never attempt to incinerate waste toner boxes.

Dispose of used toner cartridges and waste toner boxes in accordance with local regulations.

1 Open the front cover of the equipment.



2 Put your fingers in the waste toner box front grooves and take it out toward you pushing down the top latch.




⚠ WARNING

Never attempt to incinerate waste toner boxes.

Dispose of used toner cartridges and waste toner boxes in accordance with local regulations.

3 Place the waste toner box on a large sheet so as not to dirty the floor.




Note


Do not place the waste toner box with its collecting port face down.

The waste toner may spill out from the box's collecting port.

4 Take the new waste toner box out of the carton.




5 Put the used waste toner box in the plastic bag and seal it with adhesive tape.




6 Clean the slit glass.
Perform steps 5 to 9 on P.80 “The Main Chargers and Slit Glass”.

7 Push the new waste toner box securely until the upper latches click.



8 Close the front cover pressing both edges.



Refilling With Staples

Refill with staples according to the following procedures when the staples in the stapler of the finisher and saddle stitch unit run out.


📖 P.74 “Finisher”

📖 P.77 “Saddle Stitch unit”


■ Finisher

□ Finisher / Saddle Stitch Finisher

1 Open the front cover of the finisher.




2 Remove the staple cartridge.




3 Take the empty staple case out of the staple cartridge.

Pull up the empty staple case while pushing both sides as shown in the figure.



4 Fit a new staple case on the staple cartridge.


Push the staple case hook into the staple cartridge socket until you hear a click.



5 Fit the staple cartridge into the stapler.

When fitting the staple cartridge, hold the green-labeled portion of the bracket securely so that the bracket will not move.

Insert the cartridge until it is caught by the latch and fixed with a click.




6 Close the front cover of the finisher.

Tip


If the message “Check staple cartridge” remains, repeat the procedure above from steps 1 to 6.

□ Inner Finisher


1 Lift up the control panel and then open the front cover of the finisher.




2 While holding the green lever, move the finisher to the left until it stops.




3 Open the Hole Punch Unit while pushing the green lever.




4 Remove the staple cartridge.




5 Take the empty staple case out of the staple cartridge.
Pull up the empty staple case while pushing both sides as shown in the figure.




6 Fit a new staple case on the staple cartridge.
Push the staple case hook into the staple cartridge socket until you hear a click.




7 Fit the staple cartridge into the stapler.
Insert the cartridge until it is caught by the latch and fixed with a click.



- 8** Return the Hole Punch Unit to its original position.




- 9** Carefully return the finisher to its original position.



⚠ CAUTION


Do not put your hand or fingers on the top of the finisher when closing it.
They could be caught and this could injure you.

- 10** Close the front cover of the finisher.




■ Saddle Stitch unit

- 1** Open the front cover of the finisher, and pull out the Saddle Stitch unit until it stops.




2 Remove the staple cartridges.

Replace both cartridges at a time.




3 Press the buttons on both sides of the cartridge.

The transparent cover of the cartridge is lifted.




4 After the transparent cover is lifted, take the empty staple case out of the cartridge.



5 Fit the new staple case into the staple cartridge.

Insert it to the rear until it clicks.




Note


In this step, do not remove the seal bundling the staples.

6 Press down the transparent cover of the cartridge.

Press it down until it clicks.




7 Pull out straight the seal bundling the staples.




8 Fit the staple cartridge.

Insert the cartridge until it is caught by the latch of the staple cartridge and is fixed with a click.



9 Return the Saddle Stitch unit to its original position. Close the front cover of the finisher.




Cleaning the Inside of the Equipment

When the inside of the equipment needs to clean, the message “Time for cleaning. Open the front cover and follow the guidance.” is displayed. In this case, clean the inside of the equipment following the guidance displayed on the touch panel.


In addition to this, even if this message is not displayed, perform cleaning when a copied image has unevenness and/or white or color streaks in the horizontal direction.

■ The Main Chargers and Slit Glass

- 1 Open the front cover of the equipment.



- 2 Pull out the cleaner until the mark appears and return it. Repeat this 3 times for each of the 4 colors.




Note


The cleaner cannot be removed by design. Pulling it out forcibly may cause malfunction.

When only the main chargers need to be cleaned, steps 3 to 10 are unnecessary. Proceed to step 11.

- 3 Put your fingers in the waste toner box front grooves and take it out toward you pushing down the top latch.




4 Place the waste toner box on a large sheet so as not to dirty the floor.




Note

Do not place the waste toner box with its collecting port face down.
The waste toner may spill out from the box's collecting port.

5 Take out the green cleaner inside the cover.




6 Hold the cleaner with the black part on the top of the cleaner upwards.




Note

Do not touch the pad at the top of the cleaner, because the toner on the pad may stick to your hands and the cleaner pad may be stained.


7 Insert the cleaner through the service hole of each color developer unit to clean it.



- 8** Insert the cleaner all the way in, and then pull it back out. Repeat this 3 times for each color.




- 9** Attach the cleaner with its top on the right and its holding side on the left.




Note

Check that the cleaner is fixed to the cover.


- 10** Push the waste toner box securely until the upper latches click taking care not to tilt it.



- 11** Close the front cover pressing both edges.



12 Press [Finish].




Cleaning the Hole Punch Dust Bin


When the hole punch dust bin becomes full, dispose of the paper punchings following the procedure below.

■ Finisher / Saddle Stitch Finisher Hole Punch Unit

- 1** Open the Hole Punch Unit cover.



- 2** Pull out the hole punch dust bin.




- 3** Dispose of the paper punchings.

- 4** Push back in the hole punch dust bin.


- 5** Close the Hole Punch Unit cover.

■ Inner Finisher Hole Punch Unit


- 1** Lift up the control panel and then open the front cover of the finisher.




2 While holding the green lever, move the finisher to the left until it stops.



3 Open the Hole Punch Unit while pushing the green lever.




4 After moving the hole punch dust bin to the left, pull it toward you.




5 Dispose of the paper punchings.


6 Push back in the hole punch dust bin.



7 Return the Hole Punch Unit to its original position.



8 Carefully return the finisher to its original position.



⚠ WARNING

Do not put your hand or fingers on the top of the finisher when closing it.
They could be caught and this could injure you.

9 Close the front cover of the finisher.

When Printed Sheets Overflow from the Stacker


When thin, small size paper (A4-R/LT-R or smaller) is used, the end of the sheets may get stuck in the stacker walls. If 300 or more sheets are printed under such condition, some printed sheets may be pushed out of the stacker. In the case above, installing the paper exit stopper at the designated location of the stacker will increase the amount of recommended plain paper that can be loaded on to the stacker to about 500 sheets.

Notes

- When printing a large number of large size sheets such as A3 and A4/LD and LG, place the paper exit stopper back in its original location.
- When the finisher is installed in the equipment, use the paper exit stopper installed in its original location.
- When the Job Separator is installed in the equipment, attach the paper exit stopper at the designated location of the stacker.
- When a large number of large size sheets such as A3 are output to the stacker of the equipment while the finisher is installed, remove them in more than one time.


Removing the paper exit stopper from its original location

- 1 **Unfold the paper exit stopper located on the left of the stacker and remove it from its groove while pushing the fulcrum inward.**




Installing the paper exit stopper in the designated location for improving paper exit

- 1 **Turn the tip of the paper exit stopper to the left and insert the paper exit stopper fulcrum into the groove on the stacker.**



Placing the paper exit stopper back in its original location

- 1 **Remove the paper exit stopper from the groove on the stacker while pushing its fulcrum inward.**
- 2 **Install the paper exit stopper in the groove on the left of the stacker.**



WHEN SOMETHING IS WRONG WITH THE EQUIPMENT

Try the troubleshooting tips in this chapter when you think there is something wrong with the equipment. This chapter also describes the daily care for the equipment.

When You Think Something Is Wrong With the Equipment	90
General operations	90
Originals and paper	91
Regular Maintenance	93

When You Think Something Is Wrong With the Equipment

If you think there is something wrong with the equipment, check the following items.

Tips

- To see the functions of the equipment such as copy or print, refer to their operator's manuals (**Copying Guide** and **Printing Guide** respectively).
- Checking the operations or procedures may help you solve the problems. When something is unclear in the operation of the equipment or you think there is something is wrong with it, the operator's manual for the function you are using will be helpful.

■ General operations

Problem Description	Cause	Corrective Action
The equipment does not work at all.	The power cord is not securely inserted into the outlet.	Insert the power cord into the outlet until it comes to a stop.
	The main power switch is turned OFF.	Turn ON the main power switch.
No icons or signs are displayed on the touch panel. (The MAIN POWER lamp and the [POWER SAVE] button light.)	The equipment is in the Sleep mode.	Press the [POWER SAVE] button to clear the Sleep mode. Refer to Chapter 1 of the Quick Start Guide .
	The equipment is in the Deep Sleep mode.	Press the [POWER SAVE] button to clear the Deep Sleep mode. Refer to Chapter 1 of the Quick Start Guide .
No icons or signs are displayed on the touch panel. (Only the MAIN POWER lamp lights.)	The power of the equipment is not turned ON.	Press the [POWER] button.
The touch panel is dim.	The contrast of the touch panel is adjusted lower.	Adjust the contrast lighter. Refer to Chapter 1 of the MFP Management Guide .
The button on the control panel does not respond to my operation. ("Saving power - press POWER SAVE button." appears on the touch panel.)	The equipment is in the power saving mode.	Press the [POWER SAVE] button to clear the power saving mode. Refer to Chapter 1 of the Quick Start Guide .
The button on the control panel does not respond to my operation. (The MAIN POWER lamp and the [POWER SAVE] button light.)	The equipment is in the Sleep mode.	Press the [POWER SAVE] button to clear the Sleep mode. Refer to Chapter 1 of the Quick Start Guide .
	The equipment is in the Deep Sleep mode.	Press the [POWER SAVE] button to clear the Deep Sleep mode. Refer to Chapter 1 of the Quick Start Guide .
The button on the control panel does not respond to my operation. (Only the MAIN POWER lamp lights.)	The power of the equipment is not turned ON.	Press the [POWER] button.
The button on the control panel or the icon on the touch panel does not respond to my operation.	A system-related trouble has occurred.	Press the [POWER] button for at least 5 seconds to shut down the equipment.

Problem Description	Cause	Corrective Action
The window “Enter Department Code” appears.	The equipment is managed under the department management function.	Enter your department code. If you do not know it, contact the administrator of the equipment.
The window “Enter the user name and Password” appears.	The equipment is managed under the user management function.	Enter your user name and password. If you do not know them, contact the administrator of the equipment.
A message is displayed on the touch panel.	Some trouble occurred in the equipment (or the message is displayed just for an ordinary operation).	See the meaning of the message referring to the listing below. 📖 P.13 “Messages Displayed on the Touch Panel”
The equipment reboots automatically.	The auto-recovery function works because a memory or operation abnormality has been detected.	Due to rebooting, the equipment has been recovered to the normal condition. You can operate the equipment as usual.

■ **Originals and paper**

Problem Description	Cause	Corrective Action
The original is jammed.	The original is unsuited for the equipment.	Check whether the original is suitable for the equipment. For details, refer to Chapter 2 of the Paper Preparation Guide .
Paper is jammed.	The paper is unsuited for the equipment.	Check whether the paper is suitable for the equipment. For details, refer to Chapter 1 of the Paper Preparation Guide .
	The paper size setting registered for the equipment is inconsistent with paper in a tray or on the MPT.	Match the size of the paper placed in the tray or on the MPT and the size registered on the equipment. For details, refer to Chapter 1 of the Paper Preparation Guide .
	The stack of paper exceeds the loading line indicated on the side guide.	Remove some paper to set it within the height limit line indicated on the side guide.
	There is too much space between the paper and the side and end guides of the tray.	Adjust the space between the paper and the side guide or the end guide not to take much space. If the thick paper is jammed, take a little space between the paper and the side guide. For details, refer to Chapter 1 of the Paper Preparation Guide .
	Hidden jammed paper has not been removed.	Check the sign again on the touch panel to see where the jam occurred. 📖 P.18 “Clearing a Paper Jam”
Two or more sheets of paper are fed together.	Sheets of paper are stuck together.	Loosen the stack of paper well and set it again.


Problem Description	Cause	Corrective Action
Sheets are not aligned when exiting.	Sheets are not placed in the tray with correct side up for this equipment.	Check the printing side of the sheets and place them correctly. Information about the printing side may be given on the wrapping paper of the sheets. If you cannot find which side is the printing side, try printing on both sides to see if the sheets are aligned when exiting.
	The type of paper corresponding to that being used has not been set.	Check that the set paper type corresponds to the paper in use. For details, refer to Chapter 1 of the <i>Paper Preparation Guide</i> .
The message indicating no paper does not disappear even after paper is placed in the tray.	Sheets placed in the tray are not aligned.	Remove the sheets from the tray, align them, and replace them.
	The side and end guides do not match the paper size in the tray.	Adjust the side and end guides to match the paper size.
	The amount of paper placed in the Large Capacity Feeder is too small.	Place more than 10 sheets of paper in the Large Capacity Feeder.
	The paper is jammed at the end of the tray.	Pull out the tray and remove any jammed paper.
	There is something other than paper in the tray.	Do not put anything but paper in the tray.

Regular Maintenance

We recommend that you clean the following portions weekly so that the originals can always be scanned in unsoiled conditions.

Notes

- Be careful not to scratch the portions when cleaning them.
- When cleaning the surface of the equipment, do not use such organic solvents as thinner or benzene.
 - This could warp the shape of the surface or leave it discolored.
 - When using a chemical cleaning pad to clean it, follow the instructions.



1. Scanning area (surface of the long rectangular glass) / 2. Original glass

Wipe it with a soft dry cloth. If there are still stains remaining, clean with a piece of soft cloth which has been moistened with water and then squeezed well. Do not use liquids other than water (such as alcohol, organic solvents or neutral detergent).

3. Guide / 4. Platen sheet

Clean the surface as follows depending on the extent of the staining.

- Clean it with a soft cloth.
- Clean it with a soft cloth lightly moistened with water.
- Clean it with a soft cloth lightly moistened with alcohol, and then wipe with a dry cloth.
- Clean it with a soft cloth lightly moistened with watered-down neutral detergent, wipe with a cloth moistened with water, and then wipe with a dry cloth.

5. Scanning area of Dual Scan Document Feeder (surface of the long rectangular glass)

Wipe it with a soft dry cloth. If there are still stains remaining, wipe clean with a piece of soft cloth which has been moistened with water and then squeezed well. Do not use liquids other than water (such as alcohol, organic solvents or neutral detergent).

Cleaning for the front cover

When the front cover has got dirty, lightly wipe it clean with a soft cloth.

Notes

- Be careful not to scratch the parts to be cleaned.
- Do not use a hard cloth or dirty cloth or a tissue.

INDEX

C		T	
Cleaning		Toner cartridge	
hole punch dust bin.....	84	“Toner Near Empty” message.....	69
The Main Chargers and Slit Glass.....	80	Toner cartridge - “Near Empty” message.....	69
D		Toner cartridge - replacing.....	67
Deep Sleep mode.....	90	U	
Department code.....	91	User information.....	91
E		W	
Error messages		Waste toner box - replacing.....	72
touch panel.....	13		
N			
Near.....	69		
“Near Empty” toner cartridge - replacing.....	69		
P			
Paper jam.....	18		
caused by a wrong paper size setting.....	55		
locating.....	18		
occurs frequently.....	20		
tips on removing the jammed paper.....	19		
Paper jam - clearing			
ADF.....	21		
automatic duplexing unit.....	32		
Bridge Kit.....	36		
DSDF (Lower).....	23		
DSDF (Upper).....	25		
Envelope Tray.....	30		
Finisher and Hole Punch Unit.....	36		
fuser unit.....	34		
Inner Finisher and Hole Punch Unit.....	52		
Large Capacity Feeder.....	28		
MPT.....	31		
Paper Feed Pedestal.....	28		
paper transport path.....	33		
RADF (Lower).....	21		
RADF (Upper).....	21		
Saddle Stitch Finisher and Hole Punch Unit.....	42		
Saddle Stitch unit of the Saddle Stitch Finisher.....	46		
tray feeding portion.....	27		
tray of the Large Capacity Feeder.....	30		
Trays.....	29		
R			
Regular maintenance.....	93		
S			
Sleep mode.....	90		
Staple jam - clearing			
Finisher.....	60		
Saddle Stitch Finisher.....	60		
Staple jam (Finisher) - clearing			
Inner Finisher.....	62		
Saddle Stitch unit.....	65		
Staples - refilling			
Finisher.....	74		
Inner Finisher.....	75		
Saddle Stitch Finisher.....	74		
Saddle Stitch unit.....	77		

Oki Data Corporation
4-11-22 Shibaura, Minato-ku, Tokyo
108-8551, Japan

www.oki.com/printing/

