

Printer Driver for MacOS

User Guide

Revision 3

Oki Data Corporation

Table of contents

1. INTRODUCTION	2
2. OPERATING ENVIRONMENT	2
3. INSTALL PRINTER DRIVER	3
4. ADD A PRINTER	5
5. PRINT SETTINGS	7
5.1. PRINT FUNCTION	7
5.1.1. Resolution	7
5.1.2. Custom Dither	8
5.1.3. Paper Source	8
5.1.4. Paper Output	8
5.1.5. Custom Paper Series	9
5.2. AUTHENTICATION PRINT	10
5.2.1. Authentication Mode	10
5.2.2. Project	10
6. SPECIAL INSTRUCTIONS	11
6.1. REGISTER AND PRINT ON CUSTOM PAPER	11
6.2. PRINT DOCUMENT CONTAINING TWO PAGES OR MORE WITH DIFFERENT PAGE SIZES	12

1. Introduction

Related to the printer driver for the macOS, this manual describes:

- Installation procedure; and
- Instructions for the usage.

2. Operating environment


The table below lists the operating environment of the printer driver.

Category	Operating Environment
Supported OS	Mac OS X 10.9 Mavericks Mac OS X 10.10 Yosemite Mac OS X 10.11 El Capitan Mac OS X 10.12 Sierra Mac OS X 10.13 High Sierra
Language	Japanese and English
Supported printer	Teriostar LP-2050, LP-1030 (Worldwide sales model) Teriostar LP-2030, LP-1140, LP-1145 (Japan only model)

3. Install printer driver



This chapter describes the installation procedure of the printer driver.



The procedure below explains the installation of MacOS 10.13. Also follow the procedure below for the installation on the OS with the other versions.




Double-click **Teriostar2_Install_v102.pkg**.

The printer driver's installation dialog appears. Then click **Continue**
Check the product license and installation destination.






Enter the username and password with administrator privileges.




4. Add a printer

After installing the printer driver, register the printer as follows.





On the **System Preferences** window, select **Printers & Scanners**.




Click + (plus) at the dialog's lower left part.

- The procedure requires standard users to enter the username and password with administrator privilege.






Select the **IP** tab, and configure **Address**, **Protocol**, and **Queue**. After specifying **Name**, for **Use** select **Select Software....**



Enter **oki** in the searching text box. Then the Teriostar series printers appear. Select a printer to be installed, and press **OK**.




The specified printer has been added. As required, change the **Default paper size** setting.

5. Print settings

This chapter explains the print settings for the printing operation with application.

5.1. Print function




5.1.1. Resolution

The **Resolution** field specifies the resolution and dithering on the print processing.


The lower the resolution is, the shorter the print processing time is and the lower the print image quality is.

When **Custom Dither** is selected on the **Resolution** menu item, specify one from the setting values shown under the **Custom Dither** menu item.




5.1.2. Custom Dither

On the **Custom Dither** field, the specified setting value is effective only when **Custom Dither** of the **Resolution** field is selected.




5.1.3. Paper Source

On the **Paper Source** field, specify a paper supply method.




5.1.4. Paper Output

On the **Paper Output** field, specify a paper output method.



5.1.5. Custom Paper Series

On the **Custom Paper Series** field, specify a paper standard system for printing on the custom paper.



5.2. Authentication Print

Printer: LP-1030

Presets: Default Settings

Copies: 1

Pages: All

Paper Size: ISO A4 8.26 by 11.69 inches

Orientation: Portrait

Authentication Mode: Authentication Off

PIN Code:

Password:

Project:

PDF Hide Details Cancel Print

5.2.1. Authentication Mode

On the **Authentication Mode** field, select an authentication mode. According to the selected mode, corresponding text input area become effective.

Authentication Mode

- ✓ Authentication Off
- One-time Password Authentication
- PIN Code Authentication
- Password Authentication

5.2.2. Project

On the **Project** field, specify a project name as required.

Authentication Mode: Authentication Off

PIN Code:

Password:

Project:

6. Special instructions

6.1. Register and print on custom paper

Register and print on the custom paper with considering the instructions below.

On the **Paper Size** field, specify **Width** and **Height** within the printer's maximum paper size.

If the specified **Width** or **Height** exceeds the maximum paper size, the printer does not start printing.

Printer model	Supported maximum width	Supported maximum height
LP-2050	914.4mm (36inches)	15m (590.55inches)
LP-1030	914.4mm (36inches)	10m (393.7inches)
LP-2030	914.4mm (36inches)	10m (393.7inches)
LP-1140	594mm (23.39inches)	1682mm (66.22inches)
LP-1145	594mm (23.39inches)	6m (236.22inches)

Specify the paper size standard of the roll paper for printing with the registered custom paper size.

Without the standard specified, the printer does not print on the roll paper loaded in the printer.

6.2. Print document containing two pages or more with different page sizes

When the printer prints a document containing two pages or more with different page sizes, for example as follows,

First page: A4 size

Second page: A3 size

the printer does not print it with correct page sizes. Note that the second page is clipped in accordance with the first page's size.

The cause of this symptom is that the printing application is not supported.

To avoid this problem, print a document containing different page sizes by specifying page size for each page.

(End of Document/MS)